



INSTALLATION STEPS

1. Cut an 85mm (3 3/8") hole in the panel (II) allow a clearance of 55mm (2 3/16") behind the panel.
2. Remove fastening ring (I), insert gauge from front. Tighten gauge (III) using fastening ring (I).
3. Insert the wire harness (IV) firmly in the gauge (III).
4. Connect cables according to the diagram. Choose either red or yellow background light.
5. Securely fasten the GPS antenna (V), preferably outdoors (or inside front windscreen) so that it has a clear view of the sky to pick up satellite signals. Connect the antenna cable to socket on the gauge. Do not cut cable.
6. After turning power on, allow the gauge to sample satellite signal for 1 minute. The gauge will show speed in knots (SOG) and Compass (COG) only when the boat is moving. While boat is lying still all data is frozen, so the compass cannot be used as a reference until the boat is moving, when the signal is recovered.
7. All data is for reference only and should not be trusted as sole navigation source.